



Mech-Mac

Cat. No. 60-1158



You can use your Mech-Mac set to build a fantastic Space Lion with a moving head, a revolving weapons platform, and a crew inside the cockpit. With two AA batteries (not supplied), you can even make the Space Lion walk!




(parts diagrams with reference numbers and quantities, showing parts which come pre-assembled in "bubbles")


Or, you can use your imagination to create your own unique cosmic creature.

PARTS

Your Mech-Mac contains 80 pieces, including:






- body with motor
- swinging head
- four legs
- two foldable wings





BUILDING THE SPACE LION

12 illus, 4 per page (vendor's #2-13; battery installation will be separate) with callouts as in vendor's sheet, modified to reflect the way parts will be packed in our kit



INSTALLING BATTERIES

You need two AA batteries to power the Space Lion. We recommend alkaline batteries, such as RadioShack Cat. No. 23-552/557.

(vendor's illus #1)

When the Space Lion moves slowly or not at all, use a Phillips screwdriver to loosen the screw on the cover, press the tab near the screw, and remove the cover. Then replace the batteries.

OPERATION

When you have installed the batteries, set **ON/OFF** to **ON**. The Space Lion walks forward, its head moves back and forth, and the weapons platform on its back rotates.

1. Install two AA batteries into the battery compartment at the bottom of the body, as indicated by the polarity symbols (+ and -) marked inside the compartment.

Cautions:

- Use only fresh batteries of the required size and type.
 - Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
2. Insert the battery compartment cover's two tabs into the recesses near the **ON/OFF** switch.
 3. Press the tab on the other end of the cover and snap the cover into place.
 4. Use a Phillips screwdriver to tighten the screw on the cover.

(illus of **OFF/ON**
location w/callout)

Set **ON/OFF** to **OFF** to stop the Space Lion.

MAINTENANCE

To enjoy your Mech-Mac for a long time:

- If you are not going to use it for several days, remove the batteries.
- Never leave dead or weak batteries in the battery compartment.
- Clean the parts with a damp cloth occasionally to keep the Mech Mac looking new.

RadioShack Limited Warranty

This product is warranted against defects for 90 days from date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your RadioShack sales slip** as proof of purchase date to any RadioShack store. Warranty does not cover transportation costs. Nor does it cover a product subjected to misuse or accidental damage.

EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell

10/95

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

6A6

Printed in Hong Kong